

CARE AND MAINTENANCE GUIDE

GYPSUM VINYL

CLEANING GUIDELINES

- Static dust and loose dirt can be easily removed from the face of the ceiling tile by the use of a soft brush or with a vacuum cleaner. A vacuum cleaner fitted with an upholstery attachment is the most suitable. It is recommended that when brushing or vacuuming it is done in one direction only for best results.
- Pencil marks and smudges can generally be removed by the simple use of a standard gum eraser.
- More general soiling can be cleaned with spray and wipe using a damp cloth or sponge. Avoid using
 an excessive amount of water. Again wipe the tiles in one direction only. After this process any soap
 residue can be cleaned off with a clean cloth or sponge lightly dampened in clean water.
- The ceiling grid can be easily cleaned with a cloth dampened in soapy water or a mild detergent. For best results it is recommended that the tiles be removed during this process.

NB: Abrasive cleaners must not be used. Broken or excessively soiled tiles should be replaced.

For further assistance please contact your local T&R Interior Systems.

Always wear gloves when handling panels

